Communicating with Oak-D-Lite

January 23, 2023

[2]: import depthai as dai

```
pipeline = dai.Pipeline()
[]: #a mono camera is one of the left or right ones (greyscale depth perception_
      →ones). We have just created a node for the mono camera
     mono = pipeline.createMonoCamera()
     #specify that it is the left camera. Creates XLinkIn internally, connecting the
      ⇔host (the computer) TO THE device (the OAK D).
     mono.setBoardSocket(dai.CameraBoardSocket.LEFT)
     #Creates XLinkOut, and names it specifically for the given camera (can have
      →XLinkOut's for multiple cameras).
     xout = pipeline.createXLinkOut()
     xout.setStreamName("left")
     #The below links the mono camera to the actual output. Takes the output of the
      \rightarrowmono camera and putting it as the input to the XLinkOut. We are attaching\Box
      →the camera (left camera) to xLinkOut (left)
     mono.out.link(xout.input)
     #transfers all the code from the host to the actual device
     with dai.Device(pipeline) as device:
         # queries the XLinkOut from the device to the host
         queue = device.getOutputQueue(name = "left")
         #gets frame from device
         frame = queue.get()
         #getCvFrame() converts frame into the OpenCV format
         imOut = frame.getCvFrame()
         #displays frame
         cv2.imshow("Image", imOut)
```

```
[]: | #rectifiedLeft, rectifiedRight and disparity are XLinkOut nodes
     import cv2
     import depthai as dai
     import numpy as np
     def getFrame(queue): #gets the last frame from the output queue, and convertsu
      →to OpenCV format
         # Get frame from queue
         frame = queue.get()
         # Convert frame to OpenCV format and return
         return frame.getCvFrame()
     def getMonoCamera(pipeline, isLeft):
         # Configure mono camera
         mono = pipeline.createMonoCamera()
         # Set camera resolution
         mono.setResolution(dai.MonoCameraProperties.SensorResolution.THE_400_P)
         if isLeft:
             # Get Left camera
             mono.setBoardSocket(dai.CameraBoardSocket.LEFT)
         else:
             # Get Right camera
             mono.setBoardSocket(dai.CameraBoardSocket.RIGHT)
         return mono
     # NEW CODE
     def getStereoPair(pipeline, monoLeft, monoRight):
         # Configure stereo pair for depth estimation
         stereo = pipeline.createStereoDepth() #creating the stereo depth node
         # Checks occluded (when object comes too close to the device) pixels and
      ⇔marks them invalid
         stereo.setLeftRightCheck(True)
         # Configure left and right cameras to work as a stereo pair
         monoLeft.out.link(stereo.left)
         monoRight.out.link(stereo.right)
         return stereo
     def mouseCallback(event, x, y, flags, param):
         global mouseX, mouseY
         if event == cv2.EVENT_LBUTTONDOWN:
             mouseX = x
```

```
mouseY = y
if __name__ == '__main__':
   mouseX = 0
   mouseY = 640
   # Start defining a pipeline
   pipeline = dai.Pipeline()
   # Set up left and right cameras
   monoLeft = getMonoCamera(pipeline, isLeft = True)
   monoRight = getMonoCamera(pipeline, isLeft = False)
   # Combine left and right cameras to form a stereo pair
   stereo = getStereoPair(pipeline, monoLeft, monoRight) # taking the output_
 from the left and right mono cameras and putting them as input to the stereo⊔
 \hookrightarrow camera
   # Define and name output depth map,
   # xoutDepth = pipeline.createXLinkOut()
   # xoutDepth.setStreamName("depth")
   # Set XLinkOut for disparity, rectifiedLeft, rectifiedRight
   xoutDisp = pipeline.createXLinkOut()
   xoutDisp.setStreamName("disparity")
   xoutRectifiedLeft = pipeline.createXLinkOut()
   xoutRectifiedLeft.setStreamName("rectifiedLeft")
   xoutRectifiedRight = pipeline.createXLinkOut()
   xoutRectifiedRight.setStreamName("rectifiedRight")
   # Pipeline is defined, now we can connect to the device
   with dai.Device(pipeline) as device:
        →outputs defined above. Gets the frames back.
       disparityQueue = device.getOutputQueue(name = 'disparity', maxSize = 1,__
 ⇔blocking = False)
       rectifiedLeftQueue = device.getOutputQueue(name = 'rectifiedLeft',__
 →maxSize = 1, blocking = False)
       rectifiedRightQueue = device.getOutputQueue(name = 'rectifiedRight', u
 →maxSize = 1, blocking = False)
```

```
# Calculate a multiplier for colormapping disparity map
      disparityMultiplier = 255 / stereo.getMaxDisparity()
      cv2.namedWindow("Stereo Pair")
      cv2.setMouseCallback("Stereo Pair", mouseCallback)
      # Variable use to toggle between side by side view and one frame view.
      sideBySide = False
      while True:
          # Get disparity map
          disparity = getFrame(disparityQueue)
          # Colormap disparity for display
          disparity = (disparity * disparityMultiplier).astype(np.uint8)
          disparity = cv2.applyColorMap(disparity, cv2.COLORMAP_JET)
          # Get left and right rectified frame
          leftFrame = getFrame(rectifiedLeftQueue);
          rightFrame = getFrame(rectifiedLeftQueue)
      if sideBySide:
          # Show side by side view
          imOut = np.hstack((leftFrame, rightFrame))
      else:
          #Show overlapping frames
          imOut = np.uint8(leftFrame/2 + rightFrame/2)
      #converting image to colour
      imOut = cv2.cvtColor(imOut, cv2.COLOR_GRAY2RGB)
      imOut = cv2.line(imOut, (mouseX, mouseY), (1280, mouseY), (0, 0, 255), __
→2)
      imOut = cv2.circle(imOut, (mouseX, mouseY), 2, (255, 255, 128), 2)
      cv2.imshow("Stereo Pair", imOut)
      cv2.imshow("Disparity", imOut)
      # Check for keyboard input
      key = cv2.waitKey(1)
      if key == ord('q'):
          # Quit when q is pressed
          break
      elif key == ord('t'):
          # Toggle display when t is pressed
          sideBySide = not sideBySide
```

0.1 Notes:

- Depth is inversely proportional to disparity; the larger the disparity (the same image being apart due to left and right view) is, the closer that image would then be (lower depth)
- Shadowish areas are where both cameras cannot see (depth is incorrect as both cameras need to be able to see the point in order to estimate depth)
- Another reason there could be a shadow-like area (incorrect depth perception) is that usually there are two pixels at different points (seen by the different cameras), that are usually matched. If you cannot do that, depth perception will go wrong. E.g. A flat white wall will have identical pixels all around, therefore even though we may be able to see it, the two cameras won't be able to match the points because they all look the same. Even shiny surfaces face this problem.
- There is a minimum distance from the camera that the object/person must be farther than to get depth perception. If we are too close, the disparity will be very large, and Oak D is not programmed to look for such a large disparity (for efficiency purposes). This can be altered (make the search space larger), but will make the depth estimation slower. (Too close and the depth estimate will be poor as we are not searching in that disparity range)
- Scan lines will show that a point will lie on the same vertical axis (if we slice horizontally) because of image rectification.
- To find corresponding points on two different mono cameras, you would choose a point on one camera, and then move along the scan line on the other camera, but not look through the entire scan line (otherwise it would take too long), you just need a small number of points to check over.